

### Date:

Vessel	Job Type	Start Time	Finish Time
	Annual Detail (Buff)		

Tasks	Action	Completed
Degrease brows, side	When Degreasing the	
windows and	brow/superstructure and side	
superstructure	windows ensure to soap	
	between superstructure	
	overhang and windows (salt builds up in these areas, the salt cant be seen from the outside but is very visible from	
	the inside)	
Move or lift Kayaks,	When washing forward decks	
Lilypads and all yacht	make sure all yacht toys have	
toys off deck	been lifted off the deck and soap	
	washed underneath (If toys are	
	salty, soap wash and notify us in	
	comments)	
<b>Machine Cut vessel</b>	Machine cut:	
	- Hard top	
	- Superstructure	
	- Brow	
	- Bulwarks	
	- Capping Boards (around	
	stanchions)	
	- Cockpit	
	- Transom	
	- Steps	



Degrease and remove	Degrease covers whilst on vessel	
covers using Magic	using Magic Sponge, chammy	
Sponge	dry and stow in safe place (away	
	from waters edge or wind)	
Soap wash hard top or	Set up harness and safely stand	
bimini	on hard top or vantage point to	
	Soap wash Bimini. Ensure	
	underside of domes and radar	
	domes have been scrubbed.	
	While up on hard top, high	
	pressure wash nonslip and wash	
	stainless steel fittings with	
	StarClean	
	(all undersides of instruments and fittings	
	that can be seen from below)	
Soap wash clears or	Ensure clears are washed using	
windows/windscreens	softwash tool or mitt. Ensure	
	the whole clears section has	
	been passed over with sort wash	
	tool (If windy or hot work small sections	
	to ensure soap doesn't dry on clears/glass	
	as this will leave bad stewaking)	
Soap wash, side	When soap washing the	
windows and	brow/superstructure and side	
superstructure	windows ensure to soap	
	between superstructure	
	overhang and windows (salt builds	
	up in these areas, the salt cant be seen	
	from the outside but is very visible from	
Lift languall deals	the inside)	
Lift/open all deck	Open all hatches and Degrease	
hatches	out gutters, drains and inside of	
	hatch lids (If scrubbing is required, use	
	magic sponge or scotch brite)	



StarClean Stainless	Using a application pad, wash	
bow rails and fittings	hand rails and fittings to remove	
	all pitting and Tea staining	
	(Ensure to wash underside or rails and	
	inward side of fittings as rust usually hides	
	in these areas)	
Bleach non-slip High	When high pressure washing	
pressure wash	non slip use orange broom head	
	(hard bristle) gurney and bleach	
	(blue bottle) carefully scrub	
	nonslip and keep all surrounding	
	areas WET to prevent damaging	
	covers etc	
Degrease Bulwarks, in	Degrease bulwarks using soft	
and out	bristle brush. Be sure to check	
	all gutters and inside bulwarks	
	for grime build up. Usually	
	black!	
Degrease sunroof	Open sunroof and inspect	
gutters	gutters. Use a magic sponge	
	and degreaser to clean grime	
	and chammy dry. (Note face of	
	sunroof will have grime and mould)	
Acid wash and	Ensure all teak is completely	
brighten Teak deck,	soaked, apply acid and work	
flybridge steps and	across the grain of the teak.	
anchor hatches	Once acid has completely	
	absorbed into teak use rinse	
	wand to remove ALL grey. Once	
	this is complete, use brightener	
	(Ensure there are no dark spots)	
Rust and stain remove	Walk around vessel and find any	
gelcoat around	rust marks, mostly found around	
stanchions	stanchions and stailess fittings	
	and spray with rust and stain	
	, .,	



	remover (open all hatches and hose out	
	all hatch gutters)	
Chammy vessel	Chammy clears, glass and	
,	stainless steel using an	
	absorbent chammy first	
	following by a finishing chammy	
	to ensure no water drops are	
	left behind	
Machine Wax Hard	Set up harness and safely clip up	
Тор	extension lead. Machine wax all	
	smooth areas, domes, radar	
	bars and hatches. Wax all	
	stainless fittings. ( <b>Ensure all</b>	
	wax has been removed, check	
	from all angles)	
Machine Wax Super	Machine wax Super structure,	
structure, brow and	brow and Bulwarks ensuring	
Bulwarks	that cloudiness has been	
	removed. Check from left, right	
	and from below to ensure all	
	wax has been absorbed.	
Machine wax Cockpit	Machine wax transom and cock	
and transom	pit, Check from left, right and	
	from below to ensure all wax	
	has been absorbed.	
Machine wax capping	Machine wax all capping boards	
board for deck and	and around stanchions. Check	
gutters	from left, right and from below	
	to ensure all wax has been	
	absorbed.	
Hand wax clears and	Use applicator pad and wax	
glass	glass and clears in and out.	
	Check from left, right and from	



	below to ensure all wax has been removed	
Machine Wax Stainless steel	Using an applicator pad, hand wax all stainless steel hand rails and fittings. Check from left, right and from below to ensure all wax has completely been removed	
Final walk around	Once all above tasks are complete, walk around vessel with a finishing chamois and microfiber to inspect vessel for any missed spots, wax left on or water drips	

Comments:		

.....



Detailer Signature